

Manuals for obsolete pump generations, please see page 17

Product	Pump Generation	Installation	Service	Inst.& Service	Part No.
English					
Low pressure pumps		LP 1205GB			930001
ABQ	5			ABQ 0613GB	930021
ACD	6		ACD 0618GB		930031
" Shaft seal	6		ACD 1302GB		930221
ACE	3		ACE 0620GB		930351
" Shaft seal	3		ACE 1303GB		930481
" Seal guard	3		SG 0601GB		930361
" T4 double assembly				T4 1201GB	930381
ACF/UCF	4		ACF 0617GB		930051
ACG/UCG	7		ACG 0621GB		930461
LPD	1		LPD 0604GB		930371
" Shaft seal	1		LPD 1300GB		930491
LPQ	1		LPQ 0603GB		930071
Medium & high pressure		MH 1202GB			930081
D4	2		D4 0617GB		930091
D6	3		D6 0612GB		930101
E4	1		E4 0613GB		930111
GA valves				GA 0601GB	930331
German					
Low pressure pumps		LP 1205DE			930002
ABQ	5			ABQ 0613DE	930022
ACD	6		ACD 0618DE		930032
ACE	3		ACE 0620DE		930352
" Seal guard	3		SG 0601DE		930362
" T4 double assembly				T4 1201DE	930382
ACF/UCF	4		ACF 0617DE		930052
ACG/UCG	7		ACG 0621DE		930462
LPD	1		LPD 0604DE		930372
LPQ	1		LPQ 0603DE		930072
Medium & high pressure		MH 1202DE			930082
D4	2		D4 0617DE		930092
D6	3		D6 0612DE		930102
E4	1		E4 0613DE		930112
GA valves				GA 0601DE	930332
Swedish					
Low pressure pumps		LP 1205SE			930000
ABQ	5			ABQ 0613SE	930020
ACD	6		ACD 0618SE		930030
ACE	3		ACE 0620SE		930350
" Seal guard	3		SG 0601SE		930360
" T4 double assembly				T4 1201SE	930380
ACF/UCF	4		ACF 0617SE		930050
ACG/UCG	7		ACG 0621SE		930460
LPD	1		LPD 0604SE		930370
LPQ	1		LPQ 0603SE		930070
Medium & high pressure		MH 1202SE			930080
D4	2		D4 0617SE		930090
D6	3		D6 0612SE		930100
E4	1		E4 0613SE		930110
GA valves				GA 1201SE	930330

Manuals for obsolete pump generations, please see page 17.

Product	Pump Generation	Installation	Service	Inst.& Service	Part No.
Italian					
Low pressure pumps		LP 1205IT			930003
ABQ	5			english version	930023
ACD	6		ACD 0617IT		930033
ACE	3		ACE 0620IT		930353
" Seal guard	3		SG 0601IT		930363
" T4 double assembly				english version	930383
ACF/UCF	4		ACF 0616IT		930053
ACG/UCG	7		english version		930463
LPD	1		LPD 0604IT		930373
LPQ	1		LPQ 0603IT		930073
Medium & high pressure		MH 1202IT			930083
D4	2		D4 0617IT		930093
D6	3		english version		930103
E4	1		E4 0613IT		930113
GA valves				GA 1201IT	930333
Dutch					
Low pressure pumps		LP 1205NL			930005
ABQ	5			english version	930025
ACD	6		ACD 0618NL		930035
ACE	3		ACE 0620NL		930355
" Seal guard	3		SG 0601NL		930365
" T4 double assembly				english version	930385
ACF/UCF	4		ACF 0616NL		930055
ACG/UCG	7		english version		930465
LPD	1		LPD 0604NL		930375
LPQ	1		LPQ 0603NL		930075
Medium & high pressure		MH 1202NL			930085
D4	2		D4 0617NL		930095
D6	3		english version		930105
E4	1		E4 0613NL		930115
GA valves				english version	930335
French					
Low pressure pumps		LP 1205FR			930006
ABQ	5			english version	930026
ACD	6		ACD 0618FR		930036
ACE	3		ACE 0620FR		930356
" Seal guard	3		SG 0601FR		930366
" T4 double assembly				english version	930386
ACF/UCF	4		ACF 0616FR		930056
ACG/UCG	7		ACG 0621FR		930466
LPD	1		LPD 0604FR		930376
LPQ	1		LPQ 0603FR		930076
Medium & high pressure		MH 1202FR			930086
D4	2		D4 0617FR		930096
D6	3		D6 0612FR		930106
E4	1		E4 0613FR		930116
GA valves				english version	930336

Manuals for obsolete pump generations, please see page 17.

Product	Pump Generation	Installation	Service	Inst.& Service	Part No.
Spanish					
Low pressure pumps		LP 1205ES			930004
ABQ	5			english version	930024
ACD	6		ACD 0618ES		930034
ACE	3		ACE 0620ES		930354
" Seal guard	3		SG 0601ES		930364
" T4 double assembly				english version	930384
ACF/UCF	4		ACF 0616ES		930054
ACG/UCG	7		english version		930464
LPD	1		LPD 0604ES		930374
LPQ	1		LPQ 0603ES		930074
Medium & high pressure		MH 1202ES			930084
D4	2		D4 0617ES		930094
D6	3		english version		930104
E4	1		E4 0613ES		930114
GA valves				english version	930334
Russian					
Low pressure pumps		LP 1203RU			930007
ABQ	5			english version	930027
ACD	6		ACD 0617RU		930037
ACE	3		ACE 0619RU		930357
" Seal guard	3		english version		930367
" T4 double assembly				english version	930387
ACF/UCF	4		ACF 0616RU		930057
ACG/UCG	7		english version		930467
LPD	1		LPD 0604RU		930377
LPQ	1		english version		930077
Medium & high pressure		english version			930087
D4	2		english version		930097
D6	3		english version		930107
E4	1		english version		930117
GA valves				english version	930337
Portuguese					
Low pressure pumps		LP 1205PT			930009
ABQ	5			english version	930029
ACD	6		ACD 0618PT		930039
ACE	3		ACE 0620PT		930359
" Seal guard	3		SG 0601PT		930369
" T4 double assembly				english version	930389
ACF/UCF	4		ACF 0616PT		930059
ACG/UCG	7		english version		930469
LPD	1		LPD 0604PT		930379
LPQ	1		english version		930079
Medium & high pressure		english version			930089
D4	2		english version		930099
D6	3		english version		930109
E4	1		english version		930119
GA valves				english version	930339

Manuals for obsolete pump generations, please see page 17.

Product	Pump Generation	Installation	Service	Inst.& Service	Part No.
Danish					
Low pressure pumps		LP 1205DK			930008
ABQ	5			english version	930028
ACD	6		english version		930038
ACE	3		english version		930358
" Seal guard	3		english version		930368
" T4 double assembly				english version	930388
ACF/UCF	4		english version		930058
ACG/UCG	7		english version		930468
LPD	1		english version		930378
LPQ	1		english version		930078
Medium & high pressure		MH 1202DK			930088
D4	2		english version		930098
D6	3		english version		930108
E4	1		english version		930118
GA valves				english version	930338